

# BLAZE KING ANALOG CAT THERMOMETER S.Z2051

## INSTALL INSTRUCTIONS

---

### How to Install

1. Remove the face plate or shroud components covering the thermostat.
2. Unscrew and remove the fasteners holding the thermostat in place. Pay special attention to the route the thermostat wires take and the position and location of the probe.
3. Remove the old thermostat.
4. Position the new thermostat in place
5. Reinstall the previously removed fasteners. Take care to follow the same path the previous wires were running and to position the new probe in the same way.
6. Reinstall the previously removed plates or shrouds.