

BLAZE KING ANALOG CAT THERMOMETER S.Z2089

INSTALL INSTRUCTIONS

How to install

- 1.) Remove any face plate or shroud components covering the thermostat.
- 2.) Unscrew the fasteners holding the thermostat in place and remove. Pay special attention to the route the thermostat wires take and the position and location of the probe.
- 3.) Position the new thermostat in place and reinstall the previously removed fasteners. Take care to follow the same path the previous wires were running and to position the new probe in the same way.
- 4.) Reinstall any previously removed plates or shrouds.