

COMFORT BUILT VACUUM/POF SWITCH WIRE CB-SWITCHWIRE INSTALL INSTRUCTIONS

How to install

1. Unplug the power cord from the stove.
2. Remove the rear or side panel needed to access the wire you're replacing.
3. Follow the wire from the switch back to the circuit board and disconnect it.
(Refer to the [Guide To Switches](#) for details).
4. Disconnect the wire leads from the switch.
5. Connect the new wire to the switch and plug it into the open port on the circuit board.
6. Reinstall any panels that were removed to gain access to the wire.
7. Plug in the unit's power cord.