

GLOW BOY VACUUM SWITCH KS-5090-1300-AMP

INSTALL INSTRUCTIONS

How to install

1. Disconnect the power supply to the stove.
2. Remove the side panel.
3. Disconnect the hose and wires from the old switch.
4. Remove the screws from the old vacuum switch.
5. Attach the hose to the gray port on the new vacuum switch.
6. Attach wires to the new vacuum switch in the same places as the old switch.
7. Mount the new vacuum switch into place.
8. Reattach the access panel.

For further details on installation, please see these [instructions](#)