

IRONSTRIKE WIRING HARNESS H5976-AMP

INSTALL INSTRUCTIONS

How to install

1. Unplug the stove.
2. Unscrew the controller from the stove.
3. Carefully disconnect the wiring harness molex connector from the stove.
4. Unscrew and remove the stove rear access panel.
5. Disconnect the wiring harness from the connected stove components. (Removal of certain components from the stove may be necessary).
6. Connect the new wiring harness to the stove components (and reinstall any removed components). Refer to the [diagram](#) below for connection layout.
7. Connect the main molex connector to the controller.
8. Reattach the controller and stove rear access panel back onto the stove.

Diagram

