

LENNOX THERMOSTAT WIRE H3457

INSTALL INSTRUCTIONS

How to install

1. Unplug the stove power cord from the wall outlet.
2. Locate the thermostat terminal block on the back of the stove, usually next to the power cord port.
3. Loosen the two terminal screws on the terminal block and remove the jumper wire.
4. There are two wires (poles) in this thermostat cable. Attach one wire to each TSTAT terminal on the stove and one wire to the R and W value in any thermostat. Ensure that the purple wires from the harness remain connected to the terminal block and tighten the terminal screws. Make sure the wires are firmly connected to the thermostat.
5. Plug in the stove and you are ready to operate with your thermostat

Diagram

