

# PIT BOSS CONTROL BOARD CAV-01 INSTALL INSTRUCTIONS

## How To Install:

1. Unplug the grill.
2. Unscrew old controller from the hopper.
3. Disconnect wires from each moxex connector.
4. Connect wire to each moxex connector based on the coloring chart below.
5. Screw the new control board back onto the hopper.
6. Plug the grill back into the wall.

## Wiring Color Index:

- Yellow & White Wire: Connects to the draft fan (double yellow wire)
- Red & White Wire: Connects to the auger motor (double red wire)
- Purple & White Wire: Connects to the heater igniter (hot rod) (double white wire)
- Black & White Wire: Connects to the power cord (same color)
- Single Silver Wire: Connects to Grill RTD Probe
- Single Green Wire: Power cord grounding wire

## Diagrams:

