USSC HIGH TEMP THERMODISC SNAP SWITCH 80601-AMP INSTALL INSTRUCTIONS

How to install

- 1. Disconnect the unit from power.
- 2. Remove the rear or right side wiring access panel(s).
- 3. Locate the switch on the rear wall of the stove above the convection blower.
- 4. Disconnect the wires from the old switch.
- 5. Unscrew the fastening screws holding the switch in place to remove the old switch from the unit.
- 6. Replace the old switch with the new switch.
- 7. Reconnect the wires to the new switch.
- 8. Reinstall the wiring access panel(s).
- 9. Reconnect power to the stove.



Having trouble installing your part? Contact Us