

ASHLEY DISTRIBUTION BLOWER 80472A-AMP

INSTALL INSTRUCTIONS

How to install

1. Unplug the unit from the power source
2. Remove the rear panel, you may need to remove the venting from the unit depending upon your installation
3. Remove the side panel which has the controller.
4. Disconnect all of the wires from the controller and set the panel aside
5. Remove the wires for the blower which is located behind the control area
6. Remove the blower mounting screws from the rear wall of the stove
7. Install your new blower with a new gasket
8. Reconnect the blower wiring
9. Reconnect the wires to the controller (molex to molex fitting, brown wires to pressure switch BC3, BC4, white and gray wires to igniter tabs at J4 and J5, heat sensor to upper white terminal block, see diagram) and then reinstall the panel.
10. Reconnect rear panel, venting and power cord

Diagram

