

BIG HORN DIGITAL CONTROL BOARD 70120-AMP

INSTALL INSTRUCTIONS

How To Install:

1. Unplug the grill.
2. Unscrew old controller from the hopper.
3. Disconnect wires from each moxex connector.
4. Connect wire to each moxex connector based on the coloring chart below.
5. Screw the new control board back onto the hopper.
6. Plug the grill back into the wall.

Wiring Color Index:

- Orange & White Wire Connector: Connects to the fan motor
- Red & White Wire Connector: Connects to the auger gear motor
- Purple & White Wire Connector: Connects to the heater igniter (hot rod)
- Black & White Wire Connector: Connects to the power cord

Diagrams:

