

CASTLE OVERHEAT SENSOR 720106

INSTALL INSTRUCTIONS

How to Install

1. Unplug the power wire from the unit.
2. Remove the side panel closest to the motherboard.
3. Locate the sensor.
4. Follow the sensor wires back to the circuit board and disconnect the sensor from the board.
5. Using a pair of pliers, grab the end of the old sensor and gently pull it from its housing/sleeve.
6. Apply some high-temperature silicone to the metal cylinder end of the new sensor.
7. Slide the new sensor into the housing/sleeve.
8. Plug the new sensor connector into the circuit board.
9. Reinstall the side panel
10. Plug in the unit.