

COMFORTBILT HOPPER LID SWITCH HOPSWITCH1

INSTALL INSTRUCTIONS

How to install

1. Unplug the power from the unit.
2. Locate the hopper lid switch.
3. Remove the two screws holding the switch housing in place.
4. Next, remove the two screws holding the switch to the switch housing.
5. Remove the black plastic strip from the bottom of the switch to expose the wires.
6. Loosen the two screws holding the wires to the bottom of the switch & remove the wires.
7. Attach the wires in the same orientation to the new switch and tighten both screws.
8. Reattach the black plastic piece to the bottom of the switch.
9. Install the new switch into the switch housing using the two previously removed bolts.
10. Reinstall the new switch housing to the side of the hopper lid and plug in the stove.

For more information on the switch, refer to the [Component Guide](#)