

COMFORTBILT MAIN POWER SWITCH

CB MAIN SWITCH

INSTALL INSTRUCTIONS

How to install

1. Ensure the plug is removed from the main switch.
2. Remove the side panel closest to the switch.
3. Remove the spade connectors that are attached to the rear of the switch.
(Pay special attention to the location of these wires so that they can be reconnected in the same orientation).
4. Using a small flat head screw drive compresses the plastic clips on the side of the switch. This will allow the switch to separate from the back of the stove.
5. Install the new switch.
6. Reconnect the spade connectors to the back of the switch.
7. Reinstall the side panel.
8. Plug the main power cord into the back of the new switch.

Refer to the [Guide to Switches](#) for details on the switch's location, function, and troubleshooting.