

ENGLANDER DIGITAL CONTROL BOARD PU-CB14

INSTALL INSTRUCTIONS

Installation Instructions:

BEFORE REPLACING THE CONTROL BOARD, Make sure the unit has completely cooled down and that the stove has been unplugged.

1. Unplug the power cord from the wall outlet.
2. Remove the front face of the control board by pulling it forward.
3. Once the board is apart, use a pair of needle nose pliers to disconnect the wiring harness, room sensor, heat sensor, hopper lid, and vacuum switch connectors.
4. Reconnect the components previously removed to the new board.
5. Snap the front face of the control panel back into place.
6. Plug the unit into the wall outlet.