

# HARMAN DIFFERENTIAL PRESSURE SWITCH

## 3-20-6866

### INSTALL INSTRUCTIONS

---

#### How to install

1. Unplug the stove.
2. Open or remove the rear access panel.
3. Locate the Differential Pressure Switch. There is a white wire coming from the controller to one side of the switch and there are two light blue wires connected at the terminal on the other side of the switch.
  - These light blue wires run to the igniter and to the feed motor.
4. Disconnect the white wire and double blue wires from the switch.
5. Disconnect the air tube.
6. Replace the old switch with the new switch
7. Reconnect the wires and tube back to the switch. The wires should be in the same positions as on the old switch.
8. Close or replace the rear access panel.