

# HEATILATOR ECO CHOICE VACUUM SWITCH

## 3-20-6866-AMP

### INSTALL INSTRUCTIONS

---

#### How to install

1. Unplug the stove
2. Remove the rear access panel.
3. Locate the switch in the rear of the stove. There is a white wire coming from the controller to one side of the switch and there are two light blue wires connected at the terminal on the other side of the switch. These light blue wires run to the igniter and to the feed motor.
4. Disconnect the white wire and double blue wires from the switch.
5. Disconnect the air tube.
6. Replace the old switch with the new switch.
7. Connect the wires and tube back to the switch. The wires must be connected to the same locations as on the previous switch.
8. Reattach the rear access panel.