IRONSTRIKE PROOF OF FIRE SWITCH H5887 INSTALL INSTRUCTIONS

How to install

- 1. Make sure that your stove is unplugged.
- 2. Open/remove the wiring access panel. This can be on the side or rear of the stove.
- 3. Locate the switch inside the stove. The switch is located where the combustion blower is mounted, on the blower housing.
- 4. Loosen the two contact points for the wires on the switch and remove the two fork connectors using a flat head screwdriver.
- 5. Remove the two hex screws that hold the switch to the housing using a 1/4" socket wrench to remove the old switch from the exhaust housing.
- 6. Install the new switch to the housing. If your new switch does not have screws for connecting the wires, use the screws from the old switch
- 7. Reconnect your wires. It does not matter which wire goes on which terminal.
- 8. Close/reattach the wiring access panel.