

# PLEASANT HEARTH CONTROL BOARD SRV7077-050

## INSTALL INSTRUCTIONS

---

### How to install:

1. Turn the dial control to the off position and then unplug the stove.
2. Remove the right side panel by loosening the screws that attach it to the back of the appliance.
3. Disconnect the wired molex connectors from the control board. The connectors are locking molex connectors. Pinch the release tab on each connector and gently tug/ rock loose.
4. With needle nose pliers, pinch the 4 plastic pins from the rear of the unit where the control board is located and push in the pins to release and remove the old control board.
5. Carefully mount the new board to the unit with the 4 control board connector pins (the plastic pins on each corner).
  - If your new control board does not include 4 control board connector pins, you can reuse the connector pins from your old board. Pinch the 4 plastic pins from the rear of the control board unit with needle nose pliers to release the control board connectors, and then snap the pins into the new board in the same orientation as the old board.
  - **When mounting the board, the board must be oriented so the USB port is positioned at the top of the board.**
6. Reconnect the wired molex connectors to the appropriate sized slots on the control board control board.
7. Reattach the right side panel by tightening the screws that attach it to the back of the appliance.
8. Plug the stove back in.