

US STOVE COMPANY POWER SUPPLY CORD 80461

INSTALL INSTRUCTIONS

This cord is the main connection responsible for bringing power to the stove. This cord plugs into the stove's power supply and wall outlet. If your stove will not power on, verify that the end of the cord is seated into the power supply and that no fuses on the main control board are blown. If you verify that the previously mentioned items are not causing the power issue and you have confirmed that you have power at the wall outlet this cord may need to be replaced.

How to install

1. Ensure that the unit has been fully turned off.
2. Disconnect the old power cord from the wall outlet.
3. Disconnect the old power cord from the unit's power supply.
4. Connect the new power cord to the unit's power supply.
5. Connect the new power cord to the wall outlet.
6. Turn on the unit to verify proper operation.