

# WHITFIELD LOW LIMIT CERAMIC SWITCH 12057601

## INSTALL INSTRUCTIONS

---

### How to install

1. Unplug the stove
2. Open the wiring access panel on the side or back of the stove.
3. Locate the side of the stove where the combustion blower is mounted. The switch is located on the exhaust blower housing.
4. Using a flat head screw driver, loosen the two contact points for the wires and remove the two fork connectors.
5. Using a 1/4" socket wrench, remove the two hex screws that hold the switch to the housing. If your new switch does not have screws for connecting the wires, use the screws from the old switch.
6. Remove the old switch from the housing.
7. Install the new switch to the housing. Secure the switch with screws.
8. Reconnect your wires to the switch's contact points. It does not matter which wire goes on which terminal. Tighten the screws on the contact points to secure the wires.
9. Close the wiring access panel.