COMFORTBILT HOPPER LID SWITCH HopSwitch2 INSTALL INSTRUCTIONS

How to install

- 1. Unplug the power cord from the unit.
- 2. Remove the rear and side panel closest to the lower circuit board.
- 3. Locate the hopper lid switch.
- 4. Follow the wires from the hopper lid switch back to the circuit board and unplug the connector (Pay attention to the way these wires are routed).
- 5. Gently pull the switch out of its seated location.
- 6. Set the new switch in place & route the connector wires in the same orientation as they were run for the previous switch.
- 7. Attach the connector to the board.
- 8. Reinstall any previously removed panels.
- 9. Plug in the unit's power cord.